

## TECHNICAL SPECIFICATIONS

Voltage:	11–18V
LEDs:	Lumileds ZES
Colour Temperature:	5700°K
Lumens:	5000Lm per pair*
IP Rating:	IP65
Operating Temperature:	-40°C to +80°C
Expected Life:	30,000 hours

\*except 18437P - 4000Lm per pair

## WARRANTY STATEMENT

### Applicable only to product sold in Australia

Brown & Watson International Pty Ltd of 1500 Ferntree Gully Road, Knoxfield, Vic., telephone (03) 9730 6000, fax (03) 9730 6050, warrants that all products described in its current catalogue (save and except for all bulbs and lenses whether made of glass or some other substance) will under normal use and service be free of failures in material and workmanship for a period of three (3) years (unless this period has been extended as indicated elsewhere) from the date of the original purchase by the consumer as marked on the invoice. This warranty does not cover ordinary wear and tear, abuse, alteration of products or damage caused by the consumer.

To make a warranty claim the consumer must deliver the product at their cost to the original place of purchase or to any other place which may be nominated by either BWI or the retailer from where the product was bought in order that a warranty assessment may be performed. The consumer must also deliver the original invoice evidencing the date and place of purchase together with an explanation in writing as to the nature of the claim.

In the event that the claim is determined to be for a minor failure of the product then BWI reserves the right to repair or replace it at its discretion. In the event that a major failure is determined the consumer will be entitled to a replacement or a refund as well as compensation for any other reasonably foreseeable loss or damage.

This warranty is in addition to any other rights or remedies that the consumer may have under State or Federal legislation.

### IMPORTANT NOTE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Distributed by:

**Brown & Watson International Pty. Ltd.**  
Knoxfield, Victoria 3180

[www.narva.com.au](http://www.narva.com.au)


IS468 Issue 3: 28.03.24

# NARVA®

## LED SUREFIT® GEN II GLOBES

### Product Instructions

P/No. 18434, 18435, 18437, 18437P, 18438



## IMPORTANT SAFETY INFORMATION

- Precise control of the LEDs creates the correct beam pattern for Australian roads
- Reinforced housing with no filament
- LEDs life is over 30,000 hours
- In built IP rated fan provides optimised cooling (IP65)
- 5000 lumens (pair)\*

\*except 18437P - 4000Lm per pair

## IMPORTANT SAFETY INFORMATION




Before installation please follow the recommended precautions below:


- Ensure the vehicle is parked on a level surface with the handbrake engaged.
- Allow the engine and engine bay to cool to eliminate any chance of burns.
- Disconnect the battery earth cable from the vehicles battery before commencing installation or maintenance.
- Allow globes to cool before attempting to remove from headlamps (minimum 30 minutes recommended after use).
- Avoid touching the glass on halogen globes or the LED chips on LED globes.
- Do not attempt to switch the lamps on before all the connections are made.

## INSTALL


### H4 – P/No. 18434



1 Move off the chuck




2 Insert lamp body in direction of arrow




3 Connect the power cable with original car connector


### H7 – P/Nos. 18437 / 18437P




1 Pull up the socket




2 Install and fix the socket




3 Insert the lamp body in the direction of arrow



4 Screw the bulb on clockwise



5 Connect the power line with the original car lamp connector




6 Use an additional connector cable if necessary


**Note:** Once fitted, test beam and adjust orientation if required by twisting.

### H8/H9/H11 – P/No. 18435


### H8/H9/H11 – P/No. 18438



1 Insert lamp body in direction of arrow



2 Screw bulb on clockwise



3 Connect the power cable with original car connector

## TROUBLESHOOTING

Fault	Solution
<b>No illumination from both LED globes</b>	Check battery earth cable has proper connection. Check connections from vehicle harness to Surefit® LED globes.
<b>No illumination from one LED globe</b>	Check connections from vehicle harness to Surefit® LED globes. Swap Surefit® LED globe from other side, if the globe illuminates the other globe may be faulty.
<b>Partial illumination</b>	Check LED globes for damage during installation and ensure plug is tightly connected to harness correctly.
<b>Not enough light on the road</b>	Adjust vehicle headlights (refer to owner's manual).
<b>Lights flickering</b>	Install CANBUS* module (sold separately). Resistors are also available if the issue continues with a CANBUS installed.
<b>Warning light on dashboard coming on</b>	Install CANBUS* module (sold separately) to cancel warning light. Resistors are also available if the issue continues with a CANBUS installed.

**\*Note:** Some vehicles use a CANBUS system to detect when a globe is blown or faulty. LED globes draw a fraction of the current of standard halogen and incandescent globes. This may cause some systems to think the globe is faulty, resulting in a warning light on the dash or the lights flickering or pulsing. Please install the correct CANBUS module (sold separately) to eliminate this problem.  
Failure to install appropriate CANBUS module may cause an issue which may require professional attention (i.e. Dealership, Auto Electrician).